

Fig. 1




Fig. 2




Fig. 3




Fig. 4





Fig. 5

Fig. 6

	MCU Status "OK"	Any MCU Status other than "OK", e.g., "Busy" (MCU modem on-line), or "Error" (MCU hardware or software error).
HPA availability	HPA available for use by ICE Modem	HPA not available for use by ICE Modem
Permitted ICE Status	ICE Mode On or Off, as controlled by Embedded DSP and local user input	ICE Mode Off only, as controlled by Embedded DSP

Fig. 7







Fig. 8

098558360 "04060" 04060



*Fig. 9*

FIG. 10




Fig. 10






Fig. 11




Fig. 12




Fig. 13




Fig. 14

1502




Fig. 15




Fig. 16




Fig. 17




Fig. 18






Fig. 19




Fig. 20




Fig. 21